

StarMOBILE

Quick Reference Guide

Table of Contents

Device Screen Layout


Applications Use

Device Hardware And Update

Home Screen Diagram

Wireless Strength
Indicates the strength of your wireless network signal.

Battery Strength
Indicates the battery strength of the device.



Mode of Operation
Indicates the current operating state of the device.

Vehicle Connection
Indicates whether tool is connected to a vehicle.

Left Function Button
Perform the function in the lower left display. Functions vary according to the context of individual screens.

Right Function Button
Perform the function in the lower right display. Functions vary according to the context of individual screens.

Keypad Controls

Left Function Button

Perform the function in the lower left of the display screen. Functions vary according to the context of individual screens.

Network LED

Flashes green when device receives traffic from an active network.






Right Function Button

Perform the function in the lower right of the display screen. Functions vary according to the context of individual screens.

Vehicle LED

Flashes green during communication between the device and vehicle.

Power LED

LED	Description
	Powered up from internal battery – green LED off and red LED on
	Powered up from external power and not charging – green LED on and red LED off
	Powered down and not charging – both LED's off
	Powered up and charging – green LED on and red LED flashes
	Powered down and charging – green LED off and red LED flashes

Navigation Keys

Standard controls for navigation and selection within the context menus in the display screen.

Power Button

Power the device on/off



Recorder Setup

STEP 1

Navigate to **Create Recordings**

From the **Home** screen, navigate to **Create Recordings** by selecting **More Options > Custom Display**.

Select **Create Template**.



STEP 2

Follow wizard steps

Follow the instructions of the template creation wizard, pressing **Next** at the completion of each step.



STEP 3

Enter vehicle information

Select the desired **Model Year**, **Model**, and **ECU** from the drop down combo boxes.

The **Available Elements** pane will display a list of elements within that ECU.



STEP 4

Add desired data elements

Click **Add >** to add selected data element(s) to the **Selected Elements** pane.

Click **Add All >>>** to add all data elements.

Click **< Remove** or **<<< Remove All** to remove element(s) from the **Selected Elements** pane.



Continued on back

Recorder Setup

STEP 5

Enter trigger specifications

Select **Manual** to begin recording by user action. Select **Trigger on any DTC** to begin recording when a DTC is set.

Enter the number of seconds to record before and after triggering.



The screenshot shows the 'Specify Triggers' step of the 'Create Data Recording Template' wizard. It features two radio buttons: 'Manual' (selected) and 'Trigger on any DTC'. Below these are three input fields: 'Seconds before trigger' (set to 15), 'Seconds after trigger' (set to 15), and 'Total Event Size' (set to 1000000). At the bottom are 'Back', 'Next', and 'Cancel' buttons.

STEP 6

Save recording template

Enter a file name and click **Finish** to exit the wizard.



The screenshot shows the 'Save the recording template' step of the 'Create Data Recording Template' wizard. It features a single text input field for the file name, which contains the text 'My name - 12345 - 123'. At the bottom are 'Back', 'Next', and 'Cancel' buttons.

Begins on back



Vehicle Installation

STEP 1

Connect the tool to the vehicle

Connect the *StarMOBILE* tool to the Data Link Connector.

Caution: Remove *StarMOBILE* battery prior to installation if ambient temperature will exceed 122°F (50°C). Refer to instructions at DealerCONNECT or www.dcctools.com.

STEP 2

Tuck tool and route cables out of the driver's way

Ensure that the placement of the tool and routing of the cables do not impair the driver's ability to operate the vehicle. Place the tool and cables away from the control pedals in order to prevent entanglement. A loose cable may entangle a foot and prevent normal operation of the brake, clutch, and accelerator pedal.

STEP 3

Place trigger in an easily accessible location


Ensure that the trigger placement will not impair the driver's ability to operate the vehicle. The driver should be able to locate the trigger and initiate a recording without having to look away from the road.

STEP 4

Run through operation checklist

Start the engine. The yellow LED may blink momentarily, but will transition to the green LED.

Press the trigger button. The green LED will blink every second to indicate that an event file is being saved.



STEP 5

Give customer copy of instructions

Make a copy of the **Customer Instructions** found on the reverse of this card to give to the customer. Review it with the customer and answer any questions that they may have. Discuss proper use from a safety perspective with the customer.

Customer Instructions

STEP 1

Inspect tool placement

Ensure that the *StarMOBILE* tool and cables do not impair your ability to drive. A loose cable can entangle a foot and prevent normal operation of the brake, clutch, and accelerator pedal. If you are uncomfortable with the setup, ask the technician to relocate the tool and reroute the cables.

STEP 2

Inspect trigger placement


Ensure that you can easily access the trigger to initiate a recording. If you must look away from the road in order to operate the trigger, ask the technician to relocate the trigger placement.

STEP 3

Follow operating procedure

Unless instructed otherwise, you will need to press the trigger button when you want to begin recording.

Once triggered, the green LED will blink every second during recording. You will not be able to begin another recording until the current one finishes.



Event Display

STEP 1

Navigate to **Recordings List**

From the **Home** screen, navigate to **Recordings List** by selecting **More Options > View Recordings**.

Highlight the desired recording and select **View Recording**.



STEP 2

Select desired data element(s)

Check the boxes in the **Graph** column to add desired element(s) to the graph.

Uncheck the boxes to remove element(s) from the graph.



STEP 3

Manipulate graph as desired

Utilize the controls in the **Control Panel** to perform standard actions such as **Zoom In** and **Zoom Out**.



Care of the *StarMOBILE* Tool

STEP 1

Follow standard guidelines

The *StarMOBILE* tool has been designed to operate in a typical shop environment, but treating it with care will ensure its long life.

Clean the tool regularly and avoid long-term contact with harsh materials or temperatures.

Avoid using the *StarMOBILE* tool for long periods in temperatures above 122°F (50°C)

STEP 2

Care of the LCD screen

Use a clean (damp) non-abrasive cloth towel and glass cleaner (such as Mopar Window Cleaner) to clean the screen surface when necessary.

Apply cleaning solution to the towel rather than directly to the LCD screen.

STEP 3

Care of the enclosure

Use a clean (damp) non-abrasive cloth towel and a mild cleaning solution to clean the enclosure's surface.

Apply cleaning solution to the towel rather than directly to the tool enclosure.

STEP 4

Cautions and warnings

Do not allow the *StarMOBILE* tool to come into contact with strong solvents such as throttle body cleaner, brake cleaner, contact cleaner, xylene, or acetone.

Avoid exposure to brake fluid, antifreeze, and petroleum products. If exposed, remove all traces of the chemical as described above.

Avoid contact of the tool's case with high temperatures.

